

## TECHNICAL CIRCULAR No. 416 of 07th June 2017

 То:	All Surveyors/Auditors	
 Applicable to flag:	All Flags	
	Severe Weather on the High Seas	
 Reference:	Meteo for sailors	

## Severe Weather on the High Seas

Many seafarers find themselves subjected to harsh elements, and when it comes to the ocean, nothing "stirs the pot" like the wind; and the winds are a response to pressure differences.

More specifically, winds move from high to low values of pressure, and the greater the differences between the pressure fields, the faster the wind moves.

When analyzing atmospheric pressure patterns, much like a contour elevation map would indicate the steepness or grade to a hiker, tightly spaced pressure contours indicate a steep pressure change pattern, hence higher winds.

*Customer Service Center* 5201 Blue Lagoon Drive, 9<sup>TH</sup>. Floor, Miami, Fl., 33126 Tel: 1 (305) 716 4116, Fax: 1 (305) 716 4117, E-Mail:

joel@conarinagroup.com

Technical Head Office 7111 Dekadine Ct. Spring, Tx., 77379 Tel: 1 (832) 451 0185, 1 (713) 204 6380



3D render of Pressure: Winds will flow from high to low pressures, and the steeper the slope, the faster the winds.

The wind blows and the waves react as a result. Now depending on the size and location of the pressure patterns, winds and therefore waves of various sizes can be produced and travel away from their origin location. Wind waves are a result of local winds blowing across the surface of the water that eventually break or reach a shoreline.

If no deterrent is present, these waves have the ability to propagate over hundreds of miles as a result of their momentum. This is known as groundswell.

Waves can often aid a vessel along its course, acting like a turbocharged engine to work in tandem with the boats own gas/diesel power. However, there are the other instances in which the waves become the foe. Increased wave heights, including the elusive rogue waves can roll and/or even break a vessel, overpower engines or snap rudders, leaving a craft at the mercy of the winds.

While it may be easier to associate poor conditions with big patterns, sometimes small scale phenomena can produced localized increases not seen in the big picture. Two examples of this would be squall lines and water spouts.

Waterspouts can be sub-categorized into tornadic and non-tornadic, as a result of their formation source. The fair-weather types are most frequent, and are considered non-tornadic in nature,

*Customer Service Center* 5201 Blue Lagoon Drive, 9<sup>TH</sup>. Floor, Miami, Fl., 33126 Tel: 1 (305) 716 4116, Fax: 1 (305) 716 4117, E-Mail:

joel@conarinagroup.com

Technical Head Office 7111 Dekadine Ct. Spring, Tx., 77379 Tel: 1 (832) 451 0185, 1 (713) 204 6380

meaning they aren't associated with a supercell thunderstorm as are the rarer tornadic waterspouts.

Typical non-tornadic waterspouts start forming on ocean/lake surface and rise up to meet the base of a parent cloud. They tend to last less than 20 minutes and produce winds less than 70mph, which would classify it as the equivalent of an EF-0 tornado.

Tornadic water spouts are a result of a rotating cloud which produces a tornado that then descends and connects to the surface of a body of water. While limited in space and time, either type of waterspouts can locally whip up winds and waters, and boaters are advised to stay clear.

Tornadic waterspouts can also be associated with squall lines, which is a typically narrow but elongated band of intense thunderstorms. The formation of a squall line in the near or offshore waters is usually ahead with an oncoming cold front associated with a low pressure. While generally measuring about 10-20 miles wide, squall lines can stretch for hundreds of miles, and are capable of producing, tornadoes/waterspouts, damaging winds, and frequent lightning.

An incoming frontal boundary from the West or Northwest will alter winds in a location as follows: Initial winds will be from the east/southeast to south, as the winds begin blowing from the local higher pressure towards the incoming lower pressure. As the frontal boundary nears, winds will become south/southwest, finally becoming west/northwest as it departs. When a squall line approaches ahead of the frontal boundary, wind shifts can be sudden and fierce which leaves little time for vessel preparation.

From the small scale back to the large, no other weather phenomena has the power and expansive reach than that of a tropical cyclone. The amount of energy generated during the evaporation and condensation processes that produce the clouds/rain is almost 200 times the world's electrical generating abilities, while the amount generated via the wind is roughly half of the world's electrical generating abilities.

The movement across the ocean basins can generate long range swells that can be felt several hundred miles away. Navigating a vessel around the associated increases can be tricky and requires advanced knowledge of environmental factors to determine potential storm trajectories.

*Customer Service Center* 5201 Blue Lagoon Drive, 9<sup>TH</sup>. Floor, Miami, Fl., 33126 Tel: 1 (305) 716 4116, Fax: 1 (305) 716 4117, E-Mail:

joel@conarinagroup.com

*Technical Head Office 7111 Dekadine Ct. Spring, Tx., 77379 Tel: 1 (832) 451 0185, 1 (713) 204 6380* 

## **REFERENCES**:

- Weather forecast

## ATTACHMENTS: No.

Kindest Regards, Cosmin Bozenovici Naval Architect – Conarina Technical Head Office

Customer Service Center 5201 Blue Lagoon Drive, 9™. Floor, Miami, Fl., 33126 Tel: 1 (305) 716 4116, Fax: 1 (305) 716 4117, E-Mail:

joel@conarinagroup.com

Technical Head Office 7111 Dekadine Ct. Spring, Tx., 77379 Tel: 1 (832) 451 0185, 1 (713) 204 6380